Transfer Auger parts list		
Description	**Location**	**Part #**
Bearings		
SA205 Bearing		SA205-16
2 Bolt flange (2 part)		PFL205 NTL
Pulley	**Location**	**Part #**
Pulley		BK100H NTL
Pulley		BK25 3/4 NTL
Bushing		HX1NTL
Miscellaneous	**Location**	**Part #**
V-belt		B41 NTL / B40 NTL
Tires		80116 4.80/4-8
Wheel bearing 3/4"		HWDG13D ASF107-6
Spring		.125x5" 4/1
Belt	edge of hopper	2CP150-11